





# **BIOAEROSOL DETECTION AND SAMPLING**



### **EXAMPLE OF PERFORMANCE**

Rapid-E is an all-optical aerosol detector designed to instantaneously detect and identify allergens, such as pollens and spores, as well as other particulates, including air pollutants and dust. In addition to producing real-time measurements, Rapid-E also collects multiple samples of airborne particles intended for lab-based analysis at a later stage.

### Rapid-E vs manual pollen count







## SPECIFICATIONS\*

Parameter	Value
Particle size range, micrometers	0.5-100
Sample air flow, liters per minute (LPM)	2.8 (can be extended to 28.3 with concentrator)
Automatic air sampling, number of reusable filters	10
Power consumption, watts	200
Size (H x W x D), centimeters	40 × 34 × 73
Humidity, %	0-95
Weight, kilograms	20

#### \*further specifications provided upon request

Plair SA Chemin des Aulx 18 1228 Plan-les-Ouates (Geneva) Switzerland

#### Disclaimer

This publication's contents are provided as is by Plair SA. Plair makes no representations nor warranties regarding the accuracy or completeness of the contents of this publication and reserves the right to make changes to the specifications at any time without notice. All trademarks are the property of their respective owners.

- Automatic aeroallergen monitoring (pollen and spores)
- Bioaerosol research
- Air quality studies (PM10, PM2.5, PM1, and polycyclic aromatic hydrocarbons)

### **KEY FEATURES**

- Online single-bioaerosol characterization by light scattering and UV laser-induced fluorescence
- Remote, continuous and real-time monitoring
- Automatic sampling
- Outdoor and indoor operation options



### **WORKING PRINCIPLE**

Rapid-E's technology is based on morphological analysis through light scattering, and chemical analysis through high-resolution, laser-induced fluorescence, and fluorescence lifetime.

For each particle, the parameters of scattered light patterns and laser-induced fluorescence are recorded, representing a unique optical fingerprint. This analysis allows highly precise real-time species identification, with a record low rate of false positives.